



USING THE FAN-HEATER

- Place the fan-heater on a flat, dry and steady surface so that the air grids of the fan-heater will not be blocked by foreign objects.
- The distance between the front grid of the fan-heater and highly inflammable materials, curtains or furniture etc. should be at least 0.9 m.

Guarantee
Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.

- Установите тепловентилятор на ровной, сухой и устойчивой поверхности так, чтобы воздушные решётки не были заблокированы посторонними предметами.
- Расстояние между передней решёткой тепловентилятора и легковоспламеняющимися материалами, шторами или мебелью и т.п. должно составлять не менее 0,9 м.

Сделано в Китае

- Құрылғының бүтіндігін тексеріңіз, бүлінулері болған кезде құрылғыны пайдаланбаңыз.
- Құрылғының жұмыс істеу кернеуі электрлік желідегі кернеуге сәйкес келетініне көз жеткізіңіз.

Гарантиялық жағдайдағы қаралып жатқан бөлшектер дилерден тек сатып алынған адамға ғана беріледі. Осы гарантиялық міндеттілігіндегі шағымдалған жағдайда төлеген чек немесе квитанциясын көрсетуі қажет.

