


DDE DPG1001Si (apт. DPG1001Si)



DYNAMIC DRIVE EQUIPMENT

DDE DPG1001Si (apт. DPG1001Si)

Technical department

Assembly drawing

Engineer, chief designer

John Emerson Jr.

DYNAMIC DRIVE EQUIPMENT, USA

Page 1


DDE DPG1001Si (apт. DPG1001Si)

1	GB845-ST4 .8-16	SELF-TAPPING SCREW 4 .8×16	7
2	0910 .190006 .00	RUBBER,END COVER	1
3	0910 .190003 .00	GENERATOR END COVER	1
4	GB5789-FB6-12	Flange Bolt M6×12	5
5	0910 .190001 .00	FAN, ENGINE	1
6	GB41-N-10	Nut M10	2
7	GB90-W-10	Washer ø10	2
8	0910 .191200 .00	ROTOR COMP .	1
9	GB9074 .14 M6-25	SCREW-WASHER M6×25	2
10	0910 .191100 .00	STATOR COMP .	1
11	GB5789-FB5-16	Flange Bolt M5×16	3
12	0910 .190002 .00	END COVER	1
13	GB5789-FB5-12	Flange Bolt M5×12	10
14	0910 .081300 .00	MUFF . PROTECTOR Assembly . RH	1
15	0910 .080008 .00	SPRING	2
16	GB41-N-6	Nut M6	2
17	0902 .100001 .00	EXHAUST GASKET	1
18	0910 .101100 .00	MUFF .SYS .	1
19	0910 .101300 .00	COVER,UNDERSIDE	1
20	0902 .101501 .00	SPARK ARRESTER BASE	1
21	0902 .101502 .00	METAL EX . FILTER	1
22	06 .025002 .20	CLIP	1
23	0910 .061006 .00	SPRING,STARTER RETURN	1
24	0910 .061200 .00	GUIDE,ROPE HANDLE	1
25	0910 .061005 .00	GRIP,STARTER	1
26	0910 .061012 .00	COVERØGRIP	1
27	0910 .061002 .00	PATCHET,STARTER	2
28	0910 .061100 .00	CASE COMP .,RECOIL STARTER	1
29	0910 .061001 .00	PULLEY,RECOIL STARTER	1
30	10 .351400 .00	ROPE	1
31	0910 .061009 .00	SPRG .PAWL GUIDE	1
32	0910 .061007 .00	PAWL GUIDE	1
33	0910 .061008 .00	SCREW,PAWL GUIDE	1
34	0910 .080100 .00	FAN COVER COMP .	1
35	0910 .120004 .00	BUILD UP,FLYWHEEL	2
36	0910 .120100 .00	FLYWHEEL COMP .	1
37	12 .020038 .10	OIL SEAL	1
38	0910 .030100 .00	CRANKCASE	1
39	GB276-BB-6004	Radial ball bearing 6004	2
40	ST160F-1110106	Governor Shaft Washer	1
41	0910 .040106 .00	COVER,CAM	1
42	0910 .040104 .00	FLYWEIGHT	1
43	0910 .040103 .00	SPRING DECOMPRESS	1
44	0910 .040107 .00	CAM	1
45	0910 .040101 .00	CAM SHAFT	2
46	GB1099 .1-3X5X13	KEY 3X5X13	1
47	0910 .050101 .00	CRANKSHAFT	1
48	0910 .050102 .00	GEAR,DRIVE	1
49	ST188F-1030001	Wire Clip	1
50	GB9074 .3 M5-10	SCREW-SPRING WASHER M5X10	1
51	0910 .030036 .10	BOARD	1
52	07 .265265 .10	O-RING Ø26 .5×Ø2 .65	1
53	0910 .127000 .00	OIL LEVER SWITCH	1

54	0910 .120300 .00	WIRE,FLAMEOUT	1
55	GB9074 .15 M6-16	SCREW-WASHER M6×16	2
56	GB5789-FB5-20	Flange Bolt M5×20	12
57	12 .020000 .01	OIL SEAL 20X35X5	1
58	0910 .030036 .20	BOARD	1
59	0910 .030007 .00	CRANKCASE COVER	1
60	139FMD-1001001	DOWEL PIN	2
61	0910 .030035 .00	OIL NOZZLE	1
62	0910 .031000 .00	OIL DIPSTICK Assembly .	1
63	0910 .050200 .00	CONN, ROD COMP .	1
64	09 .113001 .00	PISTON PIN CLIP	2
65	0910 .050003 .00	PIN,PISTON	1
66	0910 .050005 .00	PISTON	1
67	0910 .050300 .00	PISTON RING SET	1
68	0910 .030033 .00	ELEMENT	1
69	0910 .041002 .00	VALVE LIFTER	2
70	15 .052076 .10	BUSHING Ø5 .2	1
71	0910 .091100 .00	CASE,AIR CLEANER COMP .	1
72	GB5789-FB6-15	Flange Bolt M6×15	2
73	0910 .091003 .00	ELEMENT	1
74	0910 .091200 .00	CASE,AIR CLEANER	1
75	08 .006016 .10	BOLT M6×16	2
76	GB41-N-6	Nut M6	2
77	0910 .090005 .00	GSKT .,PIPE	1
78	0910 .090004 .00	PIPE,AIR CLEANER	1
79	0910 .130004 .00	GSKT .,AIR CLEANER	1
80	0910 .130000 .00	CARBURETOR COMP .	1
81	0910 .130003 .00	GSKT .,CARB .	1
82	0910 .130001 .00	INSULATOR,CARB .	1
83	0902 .130002 .00	INSULATOR GASKET	1
84	0910 .081100 .00	MUFF .,PROTECTOR COMP ., SIDE	1
85	0910 .040005 .00	PUSH ROD,VALVE	2
86	0910 .040016 .00	SHAFT,ROCKER ARM	1
87	0910 .020001 .00	BREATHER TUBE	1
88	GB1667-S5-14	SCREW M5×14	1
89	15 .005005 .10	BUSH Ø5×5	1
90	0910 .021101 .00	CYLINDER HEAD COVER	1
91	0910 .021002 .00	COVER,BREATHER ROOM	1
92	GB1667-S3-16	Screw M3×16	4
93	0910 .020002 .00	HEAD COVER PACKING	1
94	02 .005001 .00	NUT,VALVE ADJUSTING	2
95	0910 .040009 .00	ROCKER ARM,VALVE	2
96	0910 .040012 .00	NUT,VALVE ADJUSTING	2
97	0910 .040007 .00	RET .,VALVE SPRING(IN .)	1
98	0910 .040003 .00	VALVE SPRING	2
99	0910 .040017 .00	VALVE STEM SEAL	1
100	0910 .040006 .00	EXHAUST VALVE	1
101	0910 .040002 .00	INTAKE VALVE	1
102	01 .606002 .00	EXHAUST STUD	2
103	01 .060680 .10	INTAKE STUD	2
104	ASRTC	SPARK PLUG	1
105	0910 .123000 .01	IGNITION Assembly .	1
106	GB5789-FB5-25	Flange Bolt M5×229	2

 DYNAMIC DRIVE EQUIPMENT		DDE DPG1001Si (apт. DPG1001Si)	
Technical department		Assembly drawing	
Engineer, chief designer		John Emerson Jr.	
DYNAMIC DRIVE EQUIPMENT, USA			Page 2

DDE DPG1001Si (apт. DPG1001Si)



DYNAMIC DRIVE EQUIPMENT

DDE DPG1001Si (apт. DPG1001Si)

Technical department

Assembly drawing

Engineer, chief designer

John Emerson Jr.

DYNAMIC DRIVE EQUIPMENT, USA

Page 3

DDE DPG1001Si (apт. DPG1001Si)

1	GB5789-FB6-15	FLG . BOLT M6×15	4
2	0910 .200604 .00	MOUNT RUBBER,BASE SETTING	4
3	0910 .200601 .00	BASE SETTING	1
4	GB5789-FB6-12	FLG . BOLT M6×12	7
5	02 .005002 .00	NUT M5	4
6	02 .006002 .00	NUT M6	4
7	0910 .200300 .00(Y)	COVER COMP .,RH .	1
8	GB1667-S5-14	SCREW M5×14	12
9	0910 .200800 .00(S)	ART COVER	4
10	0902 .200605 .00	MOUNT RUBBER,ENGINE	4
11	GB5789-FB6-8	FLG . BOLT M6×8	2
12	0910 .070009 .00	BRACKET,FUEL TANK	1
13	0910 .221000 .00	CONTROLLER ASSY .	1
14	GB1667-S4-14	SCREW M4×14	8
15	GB93-LW-4	SPRING WASHERΦ4	8
16	GB90-W-4	FLAT WASHERΦ4	8
17	08 .006001 .00	BOLT M6	4
18	0910 .A1	ENGINE	1
19	GB1667-S5-14	SCREW M5×14	1
20	0902 .220002 .00	MOUNT RUBBER,CONTROLLER	1
21	08 .006014 .10	BOLT M6×14	1
22	0910 .200105 .00(Y)	MAINTENANCE COVER	1
23	02 .006003 .00	NUT M6	4
24	0910 .070011 .20	PIPE,FUEL	1
25	0910 .070011 .30	PIPE,FUEL	1
26	ST152FD-1070200	PIPE,FUEL	1
27	14 .008095 .00	BUFFER	2
28	0910 .071000 .01	FUEL TANK ASSY	1
29	0910 .200400 .00(Y)	SUPPORTER,BACK COVER	1
30	IV02 .P-00000000	Parallel terminal	1
31	0910 .200200 .00(Y)	COVER COMP .LH .	1
32	GB1667-S4-14	SCREW M4×14	2
33	GB93-LW-4	SPRING WASHERΦ4	2
34	GB90-W-4	FLAT WASHERΦ4	2
35	0910 .212100 .A1(S)	OUTPUT PANEL COMP .	1
36	ST02FD-05502023-CSA	Receptacle	1
37	GB41-N4	NUT M4	2
38	0910 .212001 .00	CONTROL BOX,OUTPUT PANEL	1
39	ST02FD-05212001	Rubber plug for panel box	1

40	0902 .210001 .00	Parallel terminal	2
41	GB1667-S2-10	SCREW M2×10	4
42	GB41-N5	NUT M5	2
43	22 .012001 .02	Communication Receptacle	1
44	GB1667-S3-6	SCREW M3×6	2
45	GB93-LW-4	SPRING WASHERΦ4	2
46	GB90-W-4	FLAT WASHERΦ4	2
47	509 .210015 .01	INSULATING PAPER	2
48	GB41-N5	NUT M5	1
49	GB41-N2	NUT M2	4
50	ST02FD-05302003	breaker	1
51	ST01FD-05701001	SWITCH,FLAMEOUT	2
52	GB5789-FB5-14	BOLT M5×14	2
53	0910 .210003 .00	JACKET,CONTROL BOX	1
54	GB845-ST-2 .9X13	SELF-TAPPING SCREW 2 .9X13	2
55	GB845-ST-3 .5X13	SELF-TAPPING SCREW 3 .5X13	1
56	GB1667-S4-10	SCREW M4×10	1
57	ST168F-1070003-G	FUEL KNOB	1
58	0910 .211100 .00(S)	OPERATE PANEL COMP .	1
59	0910 .210016 .00	SPEED LIMITER	1
60	0910 .211001 .00	CONTROL BOX,OPERATE PANEL	1
61	0910 .070400 .00	FUEL COCK COMP .	1
62	0910 .126100 .00	TCI UNIT	1
63	GB5789 M6X50	BOLT M6×50	4
64	0910 .200700 .00	GRUPE COMP .	1
65	0910 .200501 .00(Y)	COVER,TOP	1
66	GB5789-FB6-20	FLG . BOLT M6×20	3
67	0910 .070900 .00	DIAPHRAGM TUBE COMP .	1
68	0910 .070011 .10	PIPE,FUEL	1
69	0910 .073000 .00	FUEL PUMP ASSY .	1
70	ST160F-1070005	clip	3
71	0902 .070300 .00	FUEL FILTER	1
72	0910 .200502 .00	SETTING,SPILL PREVENTION	1
73	0910 .200505 .00(Y)	MAINTENANCE COVER	1
74	08 .005012 .10	SCREW M5×12	1
75	0902 .070100 .00	FUEL TANK CAP COMP .	1
76	ST160F-1070007	clip	4
77	0910 .200100 .00(Y)	FRONT COVER ASSY	1
78	GB41-N6	NUT M6	4
79	GB823 M4X14	SCREW M4×14	1

		DDE DPG1001Si (apт. DPG1001Si)	
Technical department		Assembly drawing	
Engineer, chief designer		John Emerson Jr.	
DYNAMIC DRIVE EQUIPMENT, USA			Page 4