


EXPLODED VIEW



PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	QTY
1	3410298A-10	Left upper handle	1
2	3410801	Wire clip	1
3	3220298	Screw	2
4	3111098-10	Auxiliary handle assembly	1
5	3412698-10	Knob	1
6	3220698	Bolt	1
7	3410598-10	Knob	1
8	3220398	Screw	2
9	3412398-10	Carry bar	1
10	3410898-10	Front housing	1
11	3390198	Spring	1
12	3111198	Tension wheel assembly	1
13	3390298	Spring	2
14	3220298	Screw	10
15	3330298	Left cover	1
16	3220998	Cover nut	1
17	3290499	Washer	1
18	3220236	Nut	1
19	3290499	Washer	1
20	3330198	Impeller pulley bracket	1
21	3220298	Screw	3
22	3290198	Belt	1
23	32262198	Washer 2×13	1
24	3220598	Screw	3
25	3111298A	Impeller pulley assembly	1
26	3320198	Impellor shaft	1
27	3111398A-10	Impellor assembly	1
28	3412098A	Snow spade	1
29	3291499	Washer	3
30	3220905	Screw	3
31	32261198	Washer	1
32	3220298	Screw	8
33	3411798	Right cover	1
34	3220298	Screw	6
35	3111498	Motor assembly	1
35-1	3610498	Carbon brush assembly	2
36	3330398	Motor mounting bar	1
37	3220475	Screw	2
38	3410998-10	Rear housing	1
39	3220298	Screw	8
40	3111598-10	Right grill assembly	1
41	3412798	Protect pacer	1

PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	QTY
42	3111698-10	Left grill assembly	1
43	3420198	Rubber sealing ring	1
44	3310298-10	Aluminium tube	1
45	3410198A-10	Right upper handle	1
46	3410801	Wire clip	1
47	3220298	Screw	2
48	3220905	Screw	5
49	3220298	Screw	8
50	3640198	Spring wire	1
51	3410798	Power cord sle eve	1
52	3410698	Spacer	1
53	3221098	Screw	2
54	3410398-10	Switch trigger	1
55	3340111	Spring	1
56	3630198	Overload protector	1
57	3630129	Toggle switch	1
58	3410498-10	Lock-out switch	1
59	3340398	Spring	1
60	3640298	Inner connector	1
61	3050211	Wire	1
62	3411298-10	Lower housing	1
63	3290173	Washer	2
64	3220110	Screw	2