


SERIES EXPLODED VIEWS OF NAILER

9240B



ITEM NO.	PART NO.	PART NAME	Q' TY	ITEM NO.	PART NO.	PART NAME	Q' TY
1	B01-01-050220-02	SCREW	4	36	B01-01-040350-02	SCREW	1
2	AA14A-001A	EXHAUST COVER	1	37	AA69B-Y07A1	SAFETY	1
3	AA14A-002A	CYLINDER CAP	1	38	AA69B-004A	COVER	1
4	AA14A-003A	AIRPROOF CUSHION	1	39	AA69B-Y08A1	WINDING SPRING	1
5	B08-050000200	O-RING	1	40	AA69B-012A	POISE SHIM	1
6	AA14A-004A	ACTIVE VALVE CAP	1	41	AA69B-Y02A1	PUSHER	1
7	AA14A-005A	SPRING	1	42	B03-01-0040-02	E-RING	1
8	B08-010000180	O-RING	1	43	AA69B-Y03A1	BAFFLE PLATE	1
9	AA14A-Y10A1	ACTIVE VALVE	1	44	B01-06-040100-02	SCREW	2
10	B08-048000250	O-RING	1	45	AA69B-015A	AXLETREE	1
12	B08-040000250	O-RING	1	46	AA69B-018A	SPRING	1
13	B08-029700350	O-RING	1	47	AA69B-019A	SPRING LATCH	1
14	AA69B-Y05A1	DRIVER	1	48	B01-06-040060-02	SCREW	1
15	B08-038000250	O-RING	1	49	B01-06-040100-02	SCREW	2
16	B08-037500180	O-RING	1	50	AA69B-005A	LINK	1
17	B08-038000250	O-RING	1	51	B01-06-040160-02	SCREW	2
18	AA14A-010B	CYLINDER	1	52	AA69B-Y09A1	NAIL ORIENT	1
19	AA14A-011B	BUMPER	1	53	AA69B-016A	RUBBER JACKER	1
20	AA69B-008A	GAG	1	54	AA69B-001A	MUZZLE	1
21	AA69B-007A	BODY	1	55	B01-06-060200-02	SCREW	2
22	AA06A-018A	AIR HOSE CONNECTOR	1	56	AA69B-002A	MUZZLE COVER	1
23	AA17A-035A	DUST CAP	1	57	B01-06-050120-02	SCREW	3
24	B08-008750180	O-RING	2	58	B01-06-050350-00	SCREW	1
25	AA17A-011A	UP AIR CONDUIT	1	59	B04-01-050-02	SPRING WASHER	4
26	AA17A-012A	SPRING	1				
27	B08-002800190	O-RING	3	101	AA14A-Y13A1	ACTIVE VALVE CAP SET	
28	AA17A-013A	THIMBLE	1	102	AA14A-Y01A2	ACTIVE VALVE PISTON SET	
29	B08-006500150	O-RING	2	103	AA69B-Y04A1	DRIVER SET	
30	AA17A-014A	DOWN AIR CONDUIT	1	104	AA14A-Y14A1	CYLINDER SET	
31	B07-01-040-00	LOCKNUT	1	105	AA17A-Y12A1	UP AIR CONDUIT SET	
32	AA17A-Y01A1	TRIGGER SET	1	106	AA17A-Y13A1	THIMBLE SET	
33	B01-01-040300-02	SCREW	1	107	AA17A-Y14A1	DOWN AIR CONDUIT SET	
34	B07-01-040-00	LOCKNUT	1	108	AA69B-Y01A1	MAGAZINE SET	
35	AA14C-014A	SLEEVE	1				

GBA69B00301
A1