




Ref No.	Description
1	Housing 握把
2	Throttle Seat 阻風圈
3	O-Ring ○型環
4	Throttle Pin 止氣銷
5	O-Ring ○型環
6	Throttle Seat 防漏墊
7	Throttle Valve 開關閥
8	Spring 彈簧
9	Exhaust Diffuser 消音器
10	O-Ring ○型環
11	Air Inlet 進氣接頭(18牙)
12	Safety Throttle lever 板機(黑色)
13	Pin 空心銷
14	Ball bearing 後蓋軸承(#626)
15	Rear End Plate 後蓋
16	Steel Ball 鋼珠 (2)
17	Cylinder 汽缸
18	Rotor 轉子
19	Rotor Blade 葉片 (4)
20	Spindle Collar 間隔環
21	Front End Plate 前蓋
22	Ball Bearing 前蓋軸承(#6000)
23	Bevel Gear Shaft 齒輪13T
24	Clamp Nut 間隔螺帽

Ref No.	Description
25	Bushing 襯套
26	Gear Housing 本體
27	Retainer Ring 扣環(STW-7)
28	Ball Bearing 軸承(#607) (2)
29	Space Collar 間隔環
30	Bevel Gear 齒輪34T
31	Drive Ring 傳動環
32	Drive Wheel 傳動盤
33	Hex Screw 內六角螺絲(M5x10L) (2)
34	Teflon Insert 下蓋支撐塊
35	O-Ring ○型環(28x1.5)
36	Cover 下蓋
37	Screw 止付螺絲(M4x3L) (2)
38	Spring Washer 碟型墊片
39	Hex Screw 半圓內六角螺絲 (M5x8)
40	Saw Blade Guard 鋸片護弓
41	Drive Shaft 傳動軸
42	Set Screw 棒尾螺絲(M6x10L)
43	Hex Screw 固定螺絲(M6x8L)
44	Saw Blade 鋸片
45	Hex Wrench 六角扳手(3mm)
46	Cap Screw 內六角油塞(1/16x28Tx6)
47	Comfort Grip 膠套(紅色)