


EXPLODED VIEW AND PARTS LIST

MODEL: SC77XE



ITEM	PART NO.	PART NAME	Q' TY	ITEM	PART NO.	PART NAME	Q' TY
1	B01-01-040080-02	SCREW	2	35	B01-04-050050-02	SCREW	2
2	AA58A-017A	MAGAZINE BODY	1	36	AA58A-042A	PIN	1
3	AA58A-022A	CLIP	1	37	AA58A-003A	SPRING	1
4	B01-01-040060-02	SCREW	3	▲38	B08-013000180	O-RING	1
5	AA58A-014A	SCREW	2	39	AA58A-029A	REAR VALVE	1
6	B02-025110-02	PIN	1	40	AA58A-035A	DRFLECTOR CAP	1
7	AA58A-027A	SPRING	2	41	AA58D-001A	BODY	1
8	AA58A-026A	MAGAZINE SHOE	1	▲42	B08-007650180	O-RING	1
▲9	AA58A-021A	WINDING SPRING	1	43	AA58D-015A	BUSHING	1
10	AA58A-005A	ROLLER	1	▲44	B08-025400330	O-RING	1
11	AA58A-018A	BRACKET	1	45	AA58D-004A	PISTON	1
12	B02-025180-02	PIN	2	▲46	AA58D-003A	CYLINDER CAP WASHER	1
13	AA58D-Y03A1	MAGAZINE RALL	1	47	AA58D-002A	CYLINDER CAP	1
14	AA58A-028A	PUSHER	1	48	B04-01-050-02	SPRING WASHER	4
15	B02-025100-02	PIN	2	49	B01-01-050220-02	SCREW	4
16	B04-01-040-02	SPRING WASHER	1	50	AA06A-018F	AIR PLUG	1
17	B01-01-050250-02	SCREW	2	51	AA58D-011A	LATCH	1
18	AA58D-005A	SIDE PLATE	2	52	AA58D-008A	SPRING LATCH	1
▲19	AA58D-006A	JAW I	1	53	B07-04-060-00	LOCKNUT	2
▲20	AA58D-007A	JAW II	1	54	B02-030180-02	PIN	3
21	AA58A-011A	BUSHING	2	55	B07-04-050-00	LOCKNUT	2
22	AA58D-009A	MAIN FIRING PIN	1	56	AA58A-037A	SHIM	2
23	AA58D-012A	ROLLER	4	57	AA58A-038A	LOCKNUT	1
24	AA58E-010A	TRIGGER	1	58	AA58A-004A	STRAIGHT PIN	2
25	AA58A-036A	STEM	1	▲59	AA58D-010A	FIRING PIN	1
26	AA58A-030A	FRONT VALVE	1	60	B04-02-060-02	FLAT WASHER	2
▲27	B08-013000180	O-RING	1	61	AA02F-030A	MUFFLER	1
28	AA58A-034A	WASHER	2	62	GG12A	JACKET	1
29	AA58A-032A	SUPPORT	4				
30	AA58A-031A	VALVE	2	101	AA58A-Y07A1	REAR VALVE SET	
▲31	B08-007800190	O-RING	4	102	AA58A-Y05A1	VALVE SET	
32	AA58A-033A	SPACER	1	103	AA58A-Y06A1	FRONT VALVE SET	
33	B01-01-040060-02-NL	SCREW	2	104	AA58D-Y02A1	DRIVER	
34	AA58D-014A	TRIGGER GUARD	1	105	AA58A-Y10A1	VALVE COMPOSE	

Remark: Items with "▲" are vulnerable parts

GBA58D00301

A5