

ASSEMBLY INSTRUCTIONS



CHARLOTTE DINING CHAIR WITH SEAT CUSHION

FURNITURE NOT SUITABLE FOR COMMERCIAL USE


COMPONENTS / HARDWARE



PRE-ASSEMBLY PREPARATION

Before you start:

- Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
- Take care when lifting. Product should be assembled as near as possible to the point of use.
- Ensure that you have all required contents for complete assembly. 3.
- Always read the assembly instructions carefully before beginning assembly.
- The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all time.
- Do not over tighten the screws and bolts as this may damage the threads.
- 7. Failure to follow the above instructions may result in damage and or the incorrect assembly of the furniture.



STEP 1

COMPLETELY TIGHTEN ALL BOLTS AT THIS POINT. ATTACH PART B TO PART A USING BOLTS AS SHOWN BELOW. ALIGN HOLES IN PART B OVER THREADS IN PART A,

