

ИНСТРУКЦИЯ ПО МОНТАЖУ ABBER Schwarzer Diamant

AG30100B/AG30110B/AG30120B/AG30130B/AG30140B/AG30150B/
AG30160B/AG30170B

НЕОБХОДИМЫЕ ИНСТРУМЕНТЫ



СПИСОК ДЕТАЛЕЙ

						
X2	X1	X1	X2	X2	X2	X2
						
X2	X1	X2	X1	X1	X2	X8
						
4X30	X16	4X10	4X12	X4	ф3.2	X1

1

 X2  X8

РАЗМЕР	A (мм)
1000	990-1020
1100	1090-1120
1200	1190-1220
1300	1290-1320
1600	1590-1620
1700	1690-1720

2

3

 X2  X1  X8  X1

4

 X2  X2

5

 X2

6

 X8

