


RU инструкция по монтажу и эксплуатации душевых систем с термостатическим смесителем
PL instrukcja montażu i obsługi systemów prysznicowych z baterią termostatyczną
EN installation and operation manual for shower systems with thermostatic faucets
KK арналған монтаждай және експлойтасыла бойынша нұсқаулық
AZ терmostatik su kranlı dus sistemlerinin quraşdırılması ve istismarı üzre təlimat

UZ терmostatli smesiteli bor dush tizimini o'matish va foydalish bo'yicha yo'riqnomalar
KG душ түтүмнүн орноттуу жана иштетүү боюнча нускамалар
KA термостатიკалық чабыштырының өзбөрчөөлөө өзбөрчөөлөө өзбөрчөөлөө
TK терmostatiki garyjyly dus ulgamlaryny


HY սկզբանապահի նորակը գեցողի համարափի Տապարան և շամպունակ իրավակ
TJ дастурамал оид ба наасбүнүн ва истифадабарии системалар дүший бе омектакунданда термостатик
MN халун хүйтэн тортмол байлагах сэхолигчтэй шүршүүр систем угсралх ба ашиглал заавар




1




2







3




4




5**6****7****8**



9




10



11

 $38 \pm 2^{\circ}\text{C} = \text{OK}$

12



13

