



Инструкция по установке выдвижных корзин

Ширина секции	Ширина	Глубина
600	554—570	500
700	654—670	500
800	754—770	500
900	854—870	500

Шаг 1



Шаг 2



Шаг 3

