




Габаритные и установочные размеры




BXM47-A1/22




BXM47-A1/22




BXM47-A1/22




BXM47-B1/22




BXM47-A2/22




BXM47-B2/22




BXM47-A3/22




BXM47-B3/22




BXM47-A4/22



BXM47-B4/22



BXM47-A5/22



BXM47-B5/22